



## **Primecork Care and Maintenance Instructions**

### **Wall Care**

Your new Primecork wall covering will add warmth and beauty to your home or commercial setting for years to come. Following a few simple maintenance steps however, will help protect your investment.

### **Cleaning**

- Blot up spills and spots immediately (Standing or trapped moisture can penetrate into the Primecork , which can cause irreversible discoloration and damages).
- Vacuum and / or dust mop the wall to minimize abrasive grit and dirt. *Note: Do not use vacuum with beater bars.*
- If more vigorous cleaning is needed, you can clean wall with BonaX surface cleaner available from your local hardware store or [www.bona.com](http://www.bona.com) .) Sustainable Materials recommends a Terry Cloth to prevent scratching or marring of wall.
- ALWAYS WIPE DRY IMMEDIATELY until no moisture is visible on the wall. Do not use wax, polish, oil soap, abrasive cleaners, steel wool, scouring powder, or ANY appreciable amount of water
- Do not use wet mops, wet scrubbers or steam cleaners as these products may cause irreversible discoloration and damages

### **Protecting Your Investment**

- Your newly installed Primecork is made from natural wood fibers and therefore are subject to change from excessive moisture, or nonconforming environmental conditions. Remove any standing or trapped water immediately, and maintain an indoor relative humidity level of 35-55% throughout the year.